SP002V2/SP002UKV2 Sweex 2.1 Subwoofer System 175 Watt

Introduction

First of all, many thanks for purchasing this Sweex 2.1 Subwoofer System 175 Watt. This speaker set enables you to enjoy high-quality sound and the most realistic effects during films and/or games.

To ensure this product operates correctly, we advise you to carefully read this manual first. If despite this manual you still experience problems during installation or operation of this product, go to www.sweex.com and look under the heading service & support.

In order to fully enjoy the Sweex 2.1 Subwoofer System 175 Watt, it is important to observe a number of things:

Do not expose the Sweex 2.1 Subwoofer System 175 Watt to extreme temperatures. Do not place the speaker set in the direct vicinity of heating elements.
Do not use the Sweex 2.1 Subwoofer System 175 Watt in extremely dusty or moist surroundings.
Protect the speaker set against powerful shocks or jolts – they may damage the internal electronics and/or the speakers itself.
Never attempt to open the speaker set yourself – it will cause the warranty to lapse.

Contents of the box

Prior to using the Sweex 2.1 Subwoofer System 175 Watt, check if all required parts are present. The following parts must be present in the box:

- 2.1 Subwoofer System 175 Watt:
  - o 1 x Subwoofer
  - o 2 x Satellite speaker
- Audio cable (3.5 mm to 2 x plug)
- CD-ROM with manual

If one of the above parts is missing, please contact the retail outlet where you purchased the device.

Specifications

- Maximum power satellite speakers: 1.5 Watt RMS
- Maximum power woofer: 5 Watt RMS
- Magnetically shielded
- Built-in stereo amplifier
- 2 x 2.5" satellite speaker
- Volume and bass controls
- Plug and Play
- Built-in power supply
- Input: stereo plug (RCA)
- Output: stereo plug (RCA)
- Frequency range satellite: 120 Hz – 20 KHz
- Frequency range woofer: 50 Hz – 140 Hz
- Woofer diameter: 3"
- Supports: Windows 98SE, 2000 and XP

Installation of hardware



First connect the satellite speakers to the woofer. Please note that these need to be connected to the 'OUTPUT' of the woofer. The red connection (R) is for the right speaker, the white connection (L) is for the left speaker.



Subsequently, the woofer must be connected to the sound source. Once again, note the colour coding of both the audio cable and the woofer. To this end, use the 'INPUT' connection of the woofer. The red connection (R) is for the red plug, the white connection (L) is for the white plug. The 3.5 mm audio plug can be connected to the sound card or any other sound source with a 3.5 mm output connection.

Finally, plug into the mains and switch on the Sweex 2.1 Subwoofer System 175 Watt by pressing the 'POWER' button at the front. The woofer lights up in blue.

Operation

The front of the Sweex 2.1 Subwoofer System 175 Watt features 3 buttons.

Button	LED Colour	Function
POWER	Blue	Switching the Sweex 2.1 Subwoofer System 175 Watt on/off
VOLUME	Blue	Volume control button
BASS	Blue	Controls the intensity of the low tones (bass)

LED indicators

The Sweex 2.1 Subwoofer System 175 Watt has a blue LED. This is lit continuously, indicating that the speaker set is switched on.

Warranty

All products under the Sweex brand are warranted for a period of three years. We do not grant support or warranties for any software and/or (rechargeable) batteries included. If one of the above parts is missing, please contact the retail outlet where you purchased the device.

The rightful owner has and retains title to all brand names and related rights mentioned in this manual.